# Freescale P1022DS Board Support Package#

This BSP supports the Freescale P1022DS board. The P1013 mode is supported when SMP is not enabled.

## Releases#

### QNX Neutrino 6.4.1#

| Date | Version | Prerequisites | Installation Notes | Release Notes | License(s) | Maturity | Provider | Download |
|---|---|---|---|---|---|---|---|---|
| 2011-02-07 | trunk | QNX Momentics 6.4.1 | 6.4.1 Generic Notes | Here | QDL and Apache II | Released | MPC Data | Project Downloads |

### QNX Neutrino 6.5.0#

| Date | Version | Prerequisites | Installation Notes | Release Notes | License(s) | Maturity | Provider | Download |
|---|---|---|---|---|---|---|---|---|
| 2011-02-07 | trunk | QNX Momentics 6.5.0 | 6.5.0 Generic Notes | Here | QDL and Apache II | Released | MPC Data | Project Downloads |

## Features#

| Feature | Planned Availability | Format | Notes |
|---|---|---|---|
| IPL | Completed | SRC | |
| Startup | Completed | SRC | |
| Serial | Completed | SRC | |
| Ethernet | Completed | SRC | |
| NOR Flash | Completed | SRC | |
| PCI | Completed | SRC | |
| RTC | Completed | SRC | |
| SMP | Completed | BIN | |
| USB | Completed | BIN | |
| I2C | Completed | SRC | |