

Freescal P1022DS Board Support Package#

This BSP supports the Freescal P1022DS board. The P1013 mode is supported when SMP is not enabled.

Releases#

QNX Neutrino 6.4.1#

Date	Version	Prerequisites	Installation Notes	Release Notes	License(s)	Maturity	Provider	Download
2011-02-07	trunk	QNX Momentics 6.4.1	6.4.1 Generic Notes	Here	QDL and Apache II	Released	MPC Data	Project Downloads

QNX Neutrino 6.5.0#

Date	Version	Prerequisites	Installation Notes	Release Notes	License(s)	Maturity	Provider	Download
2011-02-07	trunk	QNX Momentics 6.5.0	6.5.0 Generic Notes	Here	QDL and Apache II	Released	MPC Data	Project Downloads

Features#

Feature	Planned Availability	Format	Notes
IPL	Completed	SRC	
Startup	Completed	SRC	
Serial	Completed	SRC	
Ethernet	Completed	SRC	
NOR Flash	Completed	SRC	
PCI	Completed	SRC	
RTC	Completed	SRC	
SMP	Completed	BIN	
USB	Completed	BIN	
I2C	Completed	SRC	