

# Freescale MPC8323E RDB Board Support Package#

This BSP supports the Freescale MPC8323E RDB board.

## Releases#

### QNX Neutrino 6.4#

Date	Version	Prerequisites	Installation Notes	Release Notes	License(s)	Support	Provider	Download	Source Tag
latest	trunk	QNX Momentics 6.4.0	<a href="#">6.4.0 Generic Notes</a>	<a href="#">here</a>	QDL and Apache II	Experimental	QNX	<a href="#">Project Downloads</a>	Coming Soon

## Features#

Feature	Planned Availability	Format	Notes
IPL	Completed	SRC	.
Startup	Completed	SRC	.
Serial	Completed	SRC	UART devices on RS-232 port 0-1
Ethernet	Completed	SRC	.
I2C	Completed	SRC	I2C controller
PCI	Completed	SRC	.
Flash	Completed	SRC	Generic Flash Driver

Some of these drivers are commented out in the default buildfile. To use the drivers in the target hardware, you'll need to uncomment them in your buildfile, rebuild the image, and load the image into the board.

## QNX Neutrino 6.4 Change History#

### Trunk#

- Created QNX Neutrino 6.4.0 BSP for Freescale MPC8323E RDB 1.0.0
- Built using the latest 6.4.0 toolchain