

Freescall MPC8360E MDS Board Support Package#

This BSP supports the Freescall MPC8360E MDS board.

Releases#

QNX Neutrino 6.4#

Date	Version	Prerequisites	Installation Notes	Release Notes	License(s)	Support	Provider	Download	Source Tag
latest	trunk	QNX Momentics 6.4.0	6.4.0 Generic Notes	here	QDL and Apache II	Experimental	QNX	Project Downloads	Coming Soon

QNX Neutrino 6.3.2#

Date	Version	Prerequisites	Installation Notes	Release Notes	License(s)	Support	Provider	Download	Source Tag
2008-02-05	1.0.0	QNX Momentics 6.3.x SP3 or later	6.3.2 Generic Notes	here	Apache II	QNX	QNX	QNX Download Center	none

Features#

Feature	Planned Availability	Format	Notes
Ethernet	Completed	SRC	2 QUICC Ethernet Controllers (UEC)
IPL	Completed	SRC	.
I2C	Completed	SRC	.
PCI	Completed	SRC	.
Startup	Completed	SRC	.
Serial	Completed	SRC	DUART

Some of these drivers are commented out in the default buildfile. To use the drivers in the target hardware, you'll need to uncomment them in your buildfile, rebuild the image, and load the image into the board.

QNX Neutrino 6.4.0 Change History#

Trunk#

- Created from QNX Neutrino 6.3.0 SP3 BSP for Freescall MPC8360E MDS 1.0.0
- Built using the latest 6.4.0 toolchain

QNX Neutrino 6.3.2 Change History[#]

1.0.0[#]

- Initial release under Apache II
- Includes:
 - Ethernet
 - I2C
 - IPL
 - PCI
 - Serial
 - Startup

Search Keywords: 8360, mpc8360, mds, Freescale, MPC8360, MDS