

# Freescale i.MX31 PDK Board Support Package#

This BSP supports the Freescale i.MX31 PDK board.

## Releases#

### QNX Neutrino 6.4.0#

Date	Version	Prerequisites	Installation Notes	Release Notes	License(s)	Support	Provider	Download	Kernel Benchmark
<b>Latest</b>	trunk	QNX Momentics 6.4.0	<a href="#">6.4.0 Generic Notes</a>	<a href="#">here</a>	QDL and Apache II	Experimental	QNX	<a href="#">Project Downloads</a>	
<b>2008-11-30</b>	1.0.0	QNX Momentics 6.4.0	<a href="#">6.4.0 Generic Notes</a>	<a href="#">here</a>	QDL and Apache II	QNX	QNX	<a href="#">Project Downloads</a>	<a href="#">Benchmark Downloads</a>

## Features#

Feature	Planned Availability	Format	Notes
Audio	Completed	SRC	MC13783 stereo DAC
DMA	Completed	SRC	Includes utility, library also included in BIN form
Ethernet	Completed	SRC	10 BaseT Ethernet controller: Crystal LAN CS8900A
Graphics / Video Acceleration	Completed	BIN	On-board graphics controller driver for Graphic Framework (GF)
I2C	Completed	SRC	MX31 I2C manager. Master library also included in BIN form
Serial	Completed	SRC	On-board UART: MX31 UART
SPI	Completed	SRC	MX31 SPI master controller
Startup	Completed	SRC	.
USB Host	Completed	BIN	host2 (EHCI)

Some of these drivers are commented out in the default buildfile. To use the drivers in the target hardware, you'll need to uncomment them in your buildfile, rebuild the image, and load the image into the board.

## QNX Neutrino 6.4 Change History#

### Trunk#

- Same as QNX Neutrino 6.4.0 BSP for Freescale i.MX31 PDK 1.0.0

### 1.0.0#

- Introduction of i.MX31 PDK
- Built using the latest 6.4.0 toolchain
- Support for ARM11 enabled procnto-v6
- Level 2 cache support

---

*Search Keywords: mx, i.mx, .mx31, pdk, Freescale, MX, i.MX, .MX31, PDK*