

Texas Instruments OMAP2420 SDP Board Support Package#

This BSP supports the Texas Instruments OMAP2420 SDP board.

Releases#

QNX Neutrino 6.4.0#

| Date | Version | Prerequisites | Installation Notes | Release Notes | License(s) | Support | Provider | Download |
|--------|---------|---------------------|-----------------------------------|----------------------|------------|--------------|----------|-----------------------------------|
| latest | trunk | QNX Momentics 6.4.0 | 6.4 Generic Notes | here | Apache II | Experimental | QNX | Project Downloads |

Features#

| Feature | Planned Availability | Format | Notes |
|----------------------|----------------------|--------|------------------------|
| Startup | Completed | SRC | . |
| IPL | Completed | SRC | . |
| Serial | Completed | SRC | OMAP UART Serial ports |
| Ethernet | Completed | SRC | . |
| I2C | Completed | SRC | . |
| ETFS | Completed | SRC | . |
| omap2420sdp_usb_init | Completed | SRC | USB init utility |
| USB | Completed | BIN | . |

Some of these drivers are commented out in the default buildfile. To use the drivers in the target hardware, you'll need to uncomment them in your buildfile, rebuild the image, and load the image into the board.

QNX Neutrino 6.4.0 Change History#

Trunk#

- Built using the latest 6.4.0 toolchain